












# 6mm SLIDING DOOR GUIDE




General Information


Please inspect this product upon delivery. Any missing parts or manufacturing defects must be reported immediately to the supplier. Damage or defects reported later will not be accepted. TAKE CARE WHEN HANDLING GLASS PARTS-AVOID HEAVY CONTACT BETWEEN THE GLASS EDGES AND ANY HARD SURFACE. Glass breakage claims will not be accepted after the product has been unpacked.

TOOLS REQUIRED

DESCRIPTION	PART IMAGE	DESCRIPTION	PART IMAGE
Tape measure		Drill	
Spirit level		Flat-head Screwdriver	
Pencil		Cross head Screwdriver	 PZ1
Ø6mm Drill bit		Mallet	
Ø3mm Drill bit		Silicone Sealant	

 This product is heavy and may require two people to install.

## ASSEMBLY INSTRUCTIONS - DRAWING



(1) 2x Top And Bottom Rail

(2) 2x Wall Profile

(3) 12x Screw Cap

(4) 1x Flat Fixed Panel

(5) 2x Bottom Roller

(6) 1x Moving Panel

(7) 1x Handle

(8) 8x Ø6x30 Wall

(9) 1x Upright Water Seal For Moving Panel

(10) 1x Upright Water Seal For Fixed Panel

(11) 1x Magnet Seal A

(12) 1x Magnet Seal B

(13) 6x Screw ST4x30

(14) 6x Screw ST4x16

(15) 2x Top Roller

(16) 2x Bottom Seal

(17) 2x Glass Clip L/R

(18) 2x Glass Clip Screw ST4x13

(19) 8x Screw ST3.5x30




(20) 2x Cover Cap For Upright Profile

(21) 2x Cover Cap For wall Profile L/R


## Before Installation

Please ensure that the shower tray is level and checked with a spirit level.  
The tray should be installed first. Tiles should then be tiled down to the tray.  
The enclosure can then be installed.


### Step 1 DRILLING WALL PROFILE TO THE WALL




## Step 2




## Step 3




Step 4



Step 5




Step 6




⚠ Take care not drill into glass


Step 7



## Step 8



## Step 9



**Allow 24 hours for silicone to dry before use. Silicone on the outside edge only, NOT THE INSIDE**

### Aftercare instructions

Regularly clean your shower product with warm soapy water to prevent lime scale build up. **DO NOT** use abrasive cleaning fluids or materials, or strong chemical cleaners as this will damage the product surface.



## **Check out our full range of Shower Enclosures**

Quadrant Shower Enclosures

Corner Entry Shower Enclosures

Walk in Shower Enclosures

Sliding Shower Doors

Bifold Shower Doors

Pivot Shower Doors

Hinged Shower Doors

Shower Screens

## **From Top Brands**

Coram Shower Enclosures

Mira Shower Enclosures

Hydrolux Shower Enclosures

Diamond Shower Enclosures

## **With quality shower trays to match your enclosure**

Square Shower Trays

Rectangular Shower Trays

Quadrant Shower Trays

Coram Shower Trays

Mira Flight Shower Trays

**plumbworld**  
**Big brands, small prices.**